INSTALLATION MANUAL FOR REVERSING CAMERA FOR CARGO


STEP 1











CORRECT INSTALLATION



STEP 2





CORRECT INSTALLATION



STEP 3







CORRECT INSTALLATION



STEP 4






CORRECT INSTALLATION



STEP 5









CORRECT INSTALLATION

